Ford Motor Company

CHASSIS PARTS AND PRICE LIST

PART NUMBER	PART NAME	NO. REQ'D	MODEL	YEAR
B 3705	Nut-steering & ignition lock switch terminal	2	BB, 51, 75, 79	32-7
	30629-S6 Screw-ignition switch lever	1	BB	33-4
	34952-S7 Lockwasher-ignition switch lever screw	1	BB	33-4
	24662-S Screw-steering & ignition lock switch body	2	51, 75, 79	35-7
B 3709	Brush-steering & ignition lock switch-assembly	1	BB, 51, 75, 79	32-7
B 3712	Case-steering & ignition lock switch	1	BB, 51, 75, 79	32-7
B 3729	Pin-5/32" diameter-use with 68-3686	1	BB, 51, 75, 79	34-7
B 3731	Screw-steering & ignition lock twist-off	1	BB, 51, 75, 79	32-7
48 3736	Plate-switch lever retainer	1	51, 75, 79	35-7

REAR AXLE--WORM TYPE (1928-1929)

†AA 4014-A	Housing-rear axle-RH & LH	1	AA	28
‡AA 4014-B	Housing-rear axle-RH & LH	1	AA	28-9
	353051-S Plug-oil	1	AA	28-9
	353030-S7 Fitting-lubricator	2	AA	28-9
AA 4035-A	Gasket-rear axle housing-lower	1	AA	28-9
AA 4036	Gasket-rear axle housing-upper	1	AA	28-9
	22297-S4 Bolt	13	AA	28-9
	34031-S Nut	13	AA	28-9
	72017-S Cotter	13	AA	28-9
AA 4190	Cap-rear axle housing	1	AA	28-9
	A-21222 Screw	4	AA	28-9
	353055-S Plug	1	AA	28-9
AA 4191	Gasket-rear axle housing cap	1	AA	28-9
AA 4205-A	Case-differential gear	2	AA	28-9
	22297-S4 Bolt	8	AA	28-9
	34031-S Nut	8	AA	28-9
	72016-S Cotter	8	AA	28-9
AA 4210-A	Gear-worm-7.25-1	1	AA	28-9
AA 4210-B	Gear-worm-5.17-1	1	AA	28-9
AA 4211-A	Spider-differential	1	AA	28-9
AA 4215-A	Pinion-differential	4	AA	28-9
AA 4221-A	Cone-differential bearing-assembly	2	AA	28-9
AA 4222-B	Cup-differential bearing	2	AA	28-9
†AA 4235-B	Shaft-rear axle	2	AA	28
‡AA 4235-C	Shaft-rear axle	2	AA	28-9
	351151-S Nut	2	AA	28-9
	A-22421 Washer	2	AA	28-9
	72072-S Cotter	2	AA	28-9
AA 4243-A	Key-rear hub	2	AA	28-9
AA 4245-A	Retainer-rear axle shaft outer grease-assembly	2	AA	28-9
AA 4504-B	Tube-torque-bearing sleeve & grease retainer assembly	1	AA	28-9
	A-21222 Screw	6	AA	28-9
	353047-AS7 Fitting-lubricator	1	AA	28-9
	A-4513-A Cap-universal joint housing-inner	1	AA	28-9
	A-4520-B Cap-universal joint housing-outer front	1	AA	28-9
	A-4520-C Cap-universal joint housing-outer rear	1	AA	28-9
AA 4521	Shim-universal joint housing cap	1	AA	28-9
	A-4515-A Gasket-universal joint housing inner cap	2	AA	28-9
	B-4516-A Cork-universal joint housing cap	4	AA	28-9
	20389-S7 Bolt-universal joint housing cap	6	AA	28-9
	33800-S2 Nut	6	AA	28-9
	34807-S2 Lockwasher	6	AA	28-9
	BB 4522 Bolt-cap to transmission	6	AA	28-9
	34030-S2 Nut	6	AA	28-9
	72009-S Cotter	6	AA	28-9
	AA 4522 Bolt-cap to coupling shaft rear supt.	6	AA	28-9

‡ With emergency brakes

† Without emergency brakes