GENUINE Ford PARTS

Ford Motor Company

CHASSIS PARTS AND PRICE LIST

GENUINE Ford PARTS

PART NUMBER	PART NAME	NO. REQ'D	MODEL	YEAR 19-
B 3326-B	Seat-drag link ball	2	51, 75, 79	36-7
B 3327	Spring-drag link ball seat	2	51, 75, 79	36-7
B 3328	Plug-drag link ball	2	51, 75, 79	36-7
	72071-S Cotter	2	51, 75, 79	36-7
BB 3332-A	Retainer-spindle connecting rod grease	2	BB, 51, 75, 79	32-7
BB 3333-A	Cap-spindle connecting rod grease retainer	2	BB, 51, 75, 79	32-7
BB 3332-A	Retainer-drag link grease	2	BB	32
BB 3332-A	Retainer-drag link grease-front	1	51, 75, 79	35-7
BB 3332-B	Retainer-drag link grease-rear	1	BB, 51, 75, 79	33-7
78 3332	Cover-ball stud dust	2	51, 75, 79	36-7
BB 3333-A	Cap-drag link grease retainer-front	1or2	BB, 51, 75, 79	32-7
BB 3333-B	Cap-drag link grease retainer-rear	1	BB, 51, 75, 79	32-7
01T 3333	Cover-spindle connecting rod ball dust shield	2	51, 75, 79	36-7
AA 3405-A	Rod-front radius	1	AA	28-9
AA 3405-B	Rod-front radius	1	AA	30-1
BB 3405	Rod-front radius	1	BB	32-4
*51 3405	Rod-front radius-assembly	1	51, 75, 79	35-7
B 3440	Cap-front radius rod	1	BB, 51, 75, 79	32-7
	22209-S2 Bolt	2	BB, 51, 75, 79	32-7
	34031-S Nut	2	BB, 51, 75, 79	32-7
	72016-S Cotter	2	BB, 51, 75, 79	32-7
B 3446	Bushing-front radius rod rubber	1	BB, 51, 75, 79	32-7
	72035-S Cotter	2	51, 75, 79	35-7
	72071-S Cotter-drag link ball plug	2	51	35
	20384-S2 Bolt	1	BB	32-4
	33795-S2 Nut	1	BB	32-4
	353026-S7 Lubricator fitting-lower	2	BB	32-4
	353031-AS7 Lubricator fitting-upper	2	BB	32-4
	353043-AS7 Lubricator fitting-lower-1/4"-28	2	BB	34
	353035-AS7 Lubricator fitting-upper-1/4"-	2or4	BB, 51, 75, 79	34-7
	27-Model 51-upper & lower			

STEERING GEAR

BB 3503	Steering gear assembly-less wheel & steering arm	1	BB	32-4
51 3503	Steering gear assembly-less wheel & steering arm	1	51, 75, 79	35-7
	22495-S2 Bolt-steering gear to frame	2	BB, 51, 75, 79	32-7
	34031-S Nut	2	BB, 51, 75, 79	32-7
	72016-S Cotter	2	BB, 51, 75, 79	32-7
	20411-S4 Bolt-steering gear to frame-rear	1	51	35
	33802-S2 Nut	1	51	35
	34808-S2 Lockwasher	1	51	35
B 3507	Clamp-steering column	1	BB, 51, 75, 79	32-7
	21492-S2 Bolt	1	BB, 51, 75, 79	32-7
	33798-S2 Nut	1	BB, 51, 75, 79	32-7
	34846-S2 Lockwasher	1	BB, 51, 75, 79	32-7
BB 3509	Tube-steering column-& bushing assembly	1	BB	32-4
51 3509	Tube-steering column-& bushing assembly	1	51, 75, 79	35-7
BB 3517	Bushing-steering shaft	1	51	32-4
BB 3524	Shaft-steering-& worm assembly	1	BB	32-4
51 3524	Shaft-steering-& worm assembly	1	51, 75, 79	35-7
B 3527	Retainer-steering gear housing oil seal	1	BB, 51	32-4
B 3528	Seal-steering gear housing oil	1	BB, 51	32-4
B 3529	Silencer-steering gear lighting switch	1	75, 79	37
BB 3532	Sleeve-steering shaft lock	1	BB, 51, 75, 79	32-7
	B-3588 Screw	2	BB, 51, 75, 79	32-7
81A 3533	Grommet-steering shaft	1	BB, 51, 75, 79	32-7
B 3538	Plug-steering gear oil filler	1	BB, 51, 75, 79	32-7
BB 3548	Housing-steering gear-& stud assembly	1	BB, 51, 75, 79	32-4
BB 3552	Cup-steering worm bearing-lower	1	BB, 51, 75, 79	32-4
BB 3553	Cup-steering worm bearing-upper	1	BB, 51, 75, 79	32-4
BB 3562	Washer-steering worm thrust-assembly	1	BB, 51, 75, 79	32-4
B 3568	Plate-steering gear housing end	1	BB, 51	32-4
	20324-S2 Screw	2	BB, 51, 75, 79	32-7
	34805-S2 Lockwasher	2	BB, 51, 75, 79	32-7
B 3569	Bracket-steering gear lighting switch	1	BB, 51, 75, 79	32-7
	* Used with 51-3105-6			