13820-A

...ND.

Instructions for Relay Installation

1. Remove rear cover of horn (1 screw)
2. Remove YELLOW wire from horn terminal and connect it to wire (1) from relay. The YELLOW wire.
3. Connect wire (3) RED from relay to the vacant horn terminal from which the YELLOW wire was removed.
4. Remove Blue-Yellow tracer wire from the other horn terminal and connect it to wire (2) BLACK from the relay.
5. Connect wire (4),the seperate black wire with the bullet connector, to the vacant horn terminal,from which the Blue-Yellow tracer was removed. Connect this wire to ground on the horn frame.

