

INSERT WIRES IN PLASTIC PLUG
PLUG IS CODED FOR THE COLOR
OF THE WIRES

1



SEAT PLASTIC PLUG AGAINST
AGAINST CONDUIT

2



3

PUSH PLUG INTO SOCKET ON UNDERSIDE
OF HEADLIGHT (ONLY FITS ONE WAY!)



HOLDING PLUG INTO HEADLIGHT, TURN
FERRULE CLOCKWISE TO LOCK ON

4

