how to wire Model 900 and 901 Switch

1. Mount switch on steering column as shown on page 1.
2. Remove flasher from harness during wiring. Replace flasher only after wiring is completed and checked.
3. Check front parking light bulbs. Bulb number should be: No. 1129 or 81 for 6v systems; No. 1073 for 12v systems; and No. 307 for 24v systems. Check tail light sockets for double contact.
4. Wire as indicated in accompanying diagram.
5. Tape ends of unused wires to prevent shorts.
6. Replace flasher to complete installation.

