
Model A Ford
TWO TOOTH STEERING GEAR
1929-1931



CLICKING ON THE RED NUMBERS OR CIRCLES WILL TAKE YOU TO THE PRODUCT DESCRIPTION AND QUICK ORDER FORM

Index #	Part #	Description	No. Required
1,2	A-3569-MB	Switch Bracket Bolts/L.W.	1 set
3	A-3569	Light Switch Bracket	1
4	A-3568-T	Housing End Plate	1
5,6,29	A-3581-BS	Steering Housing Gasket Set	1
7	A-3577	Sector Thrust Screw	1
8	A-3578	Thrust Screw Jam Nut	1
9	Not Available	Thrust Screw Lock washer	1
10	Not Available	Steering Gear Housing	1
11	A-3538 or -A	Oil Fill Plug	1
12,13	A-3554	Adjusting Bolt/Nut	1
14,15,16	A-3555-MB	Clamp Bolt/Nut/Lock Washer	1 set
17	A-3552	Lower Race	1
18	A-3571	Worm Bearing	2
19	A-3524-CD	Worm Gear	1
20	A-3553-D	Upper Race	1
21	A-3507	Steering Column Clamp	1
22,23,24	A-3507-MB	Clamp Bolt/Nut/Lock Washer	1 set
25	A-3524-43/44-G	Steering Shaft	1
26	A-3584	Eccentric Rivet	1
27	A-3575-CS	Two Tooth Sector	1
28	A-3579	Sector Thrust Washer	1
30	A-3576-C	Sector Bushings	2
31	A-3548-NOR	Sector Housing	1
32	A-3586	Eccentric Adjusting Sleeve	1
33	A-3587	Eccentric Adjusting Cone	1
34	A-3549-W	Large Diameter Lock Washers	4
35	A-3549-N	Large Diameter Nuts	4
36	A-3585	Eccentric Stud	1
37	A-3549-ST	Housing Studs	3
38	A-3527	Lower Seal Retainer	1

#38 is not needed if using A-3568-T end plate with tube.