



**EVR replaces
third brush**

**Field coil wire
attaches to screw**

**EVR lead attaches
to brush which is
connected to
generator output
terminal**

**EVR mounting
screw and GRD
connection**