
Part # C809
Specs: Primary 1.0 - 1.4 / Secondary 5.8k - 9.2k

Should The Coil Fail Any Of These Steps, It Must Be Replaced

1. Look for corroded or discolored terminals
2. Look for carbon tracks (Burned) or cracking anywhere on coil
3. Look for oil leakage, mainly through secondary tower



© 2012 WELLS VEHICLE ELECTRONICS ALL RIGHTS RESERVED. NO PORTION OF THIS MANUAL MAY BE REPRODUCED WITHOUT THE PERMISSION OF WELLS VEHICLE ELECTRONICS.