

1/16 x 1/2 MS24665-132 - Brake cross shaft frame bracket Rear engine support rods	3/32 x 1/2 MS24665-281 - Hand brake lever rod Front radius rod retaining pin Clutch pedal shaft collar pin	3/32 X 5/8 MS24665-282 - Front brake plate assy E-Brake toggle conn link Hand brake lever sector U-Joint outer cap Tail pipe clamp Engine connecting rods Throttle bell crank Shock arm bolts Radiator mounting bolts	3/32 X 3/4 MS24665-283 - Operating wedge stud assy Spindle connecting rod end Steering gear housing bolt Steering gear arm Fan shaft Main engine bearings Front engine support Spring shackles Rear radius rear bolts Front spring U-bolts Rear backing plate bolts	3/32 X 1 MS24665-285 - Front radius ball cap Pinion castle nut	5/32 x 1 MS24665-419 - Spindle to drum
1/8 x 5/8 MS24665-350 - Brake pedal clevis pin Brake pedal rod to cross shaft Brake rod adjusting clevis Hand brake lever pawl pin E-brake lever to cross shaft rod E-brake cross shaft to rear end Clutch pedal to release shaft arm trunion	1/8 x 3/4 MS24665-351 - Brake shoe roller pins	1/8 x 1 MS24665-353 - Front spring perch Spindle arm Rear axle to drum Rear radius rod - front bolt Rear spring retaining bar	1/8 x 1-1/4 MS24665-355 - Side mount arm support Shock link plug	1/8 x 1-1/2 MS24665-357 - Spindle connecting ball plug Drag link ball plug	3/16 X 1 MS24665-491 - Flywheel clean out hole