

- Battery +
Dist
-
+
Coil
Resistor
BAT
IGN
SW
RUN
ST
Start
Sol
Starter