PART NUMBER	PART NAME	NO. REQ'D	MODEL	YEAR
3571-A	Roller-steering worm bearing-assembly	2	BB,51,75,79	32-7
3572	Sector-steering worm	1	BB	32-4
3575	Sector-steering worm	1	51,75,79	35-7
3576-A	Bushing-steering worm sector	2	BB,51,75,79	32-7
3579	Washer-steering worm sector thrust	1	BB,51,75,79	32-7
	B-3577 Screw-steering worm sector thrust-headless-slotted	1	BB,51,75,79	32-7
	351075-S Nut	1	BB,51,75,79	32-7
	34803-S7 Lockwasher	1	BB,51,75,79	32-7
3582	Seal-steering gear housing oil	1	BB	32-4
3583	Cover-steering housing-& bushing assembly	1	51,75,79	35-7
3583	Cover-steering gear housing-& bushing assembly	3	BB,51,75,79	32-7
	352700-S Stud	3	BB,51,75,79	32-7
	356004-S7 Nut	3	BB,51,75,79	32-7
	351376-S Lockwasher	1	BB,51,75,79	32-7
3581	Gasket-steering gear housing cover	1	BB,51,75,79	32-7
3584	Rivet-steering gear housing eccentric	1	BB,51,75,79	32-7
3585	Stud-steering worm housing cover adjusting	1	BB,51,75,79	32-7
	356004-S7 Nut	1	BB,51,75,79	32-7
	34807-S2 Lockwasher	1	BB,51,75,79	32-7
3586	Sleeve-steering worm eccentric adjusting	1	BB,51,75,79	32-7
3587	Ring-steering worm eccentric adjusting sleeve lock	1	BB,51,75,79	32-7
3589-A	Cap-steering housing-upper	4	BB,51,75,79	32-7
	20346-S2 Bolt	4	BB,51,75,79	32-7
	34846-S2 Lockwasher	1	BB	32
3590-A	Arm-steering gear	1	BB	33-4
3590-B*	Arm-steering gear	1	51,75,79	35-7
3590	Arm-steering gear	1	BB,51,75,79	32-7
	351153-S Nut	1	BB,51,75,79	32-7
	34814-S Lockwasher	1	51,75,79	35-7
	72089-S Cotter	1	75,79	37
	40-3592 Plate-steering gear housing end	1	BB,51,75,79	32-7
3593	Gasket-steering gear housing cap-upper-thin	1	BB,51,75,79	32-7
3594	Gasket-steering gear housing cap-upper-thick	1	75,79	37
	40-3597 Tube-steering gear oil retainer-assembly	1	BB,51,75,79	32-7
3600-B	Wheel-steering-assembly	1	BB,51,75,79	32-7
	33947-S2 Nut-steering wheel	1	BB,51,75,79	32-7
3609	Key-steering wheel	1	BB	32-4
3616	Handle-lighting switch-& horn switch assembly	1	51,75,79	35-7
3616	Handle-lighting switch-& horn switch assembly	1	BB,51,75,79	32-7
3639	Insulator- horn wire terminal-lower	1	BB,51,75,79	32-7
3642	Spring-lighting switch operating spider	1	BB,51,75,79	32-7
3643	Spider-lighting switch operating	1	BB,51,75,79	32-7
3644	Retainer-lighting switch operating spider	1	BB	32-4
3647-A	Bail-steering gear lighting switch-use with long cover	1	BB,51	32-6
3647-B	Bail-steering gear lighting switch-use with B-11655-B - 8 cyl.	1	75,79	37
3647	Bail-steering gear lighting switch	1	BB	32-4
3676	Lock-steering & ignition-assembly-less cylinder, keys & retaining pin	1	51,75,79	35-7
3676	Lock-steering & ignition-assembly-less cylinder, keys & retaining pin	1	BB,51	32-5
	B-3686 Cylinder-steering & ignition lock-& 2 keys	1	BB,51,75,79	34-7
	91A 3686-A Cylinder-steering & ignition lock -& 2 keys-5/32" dia. pin hole	1	BB,51	32-5
	B-3729 Pin-steering & ignition lock retaining-5/32" diameter	1	51,75,79	35-7
	68-3729 Pin-cylinder lock-9/32" diameter	2	BB,51,75,79	32-7
	20357-S2 Bolt-front belt rail finish panel to steering gear & ignition lock	2	BB,51,75,79	32-7
	34806-S2 Lockwasher	1	51,75,79	35-7
	36801-S2 Screw	1	51,75,79	35-7
	34804-S2 Lockwasher	1	BB	32-4
3682	Shim-steering & ignition lock	1	51,75,79	35-7
3682	Shim-steering & ignition lock	2	BB,51,75,79	32-7
A 3685	Key-steering & ignition lock			