1
2
3
4
Coil
Blk
Orn
MSD Bypass Connector
MSD Bypass Connector
Blk
Red
Petronix
Ignitor II
Distributor
Ylw
Power Distribution Plate Mounted behind Fuel Tank
MSD
IGNITION
Multiple
Spark
Discharge
MSD 6A
Blk (Large)
Red (Large)
Wht
Red
Orn
Blk
Red
Horn
Blue
10A
Lights
Ylw
20A
5A
Ign
Control
Acc
Outlet
10A
10A
Starter
Ign Pwr
20A
5A
Fuel
Pump
Roll Over
Switch
Red
Ignition Switch
#10
Ylw
60A
Shunt
Fuel
Pump
Relay
Starter Switch
#8
Blk
#8
Red
Ylw
Ylw
Main
Fuse
60A
Junction
Box
Ammeter
Battery
Disconnect
N
S
S
N
M
60Amp
Alternator
Starter
Fuel Pump