Rear Bumper

1941

PASSENGER-SUPER DELUXE EXCEPT STATION WAGON



11A 17757-A	Bar	1
11A 17787-B	Arm (inner)-RH	1
11A 17788-B	Arm (inner)-LH	1
11A 17795-B	Arm (outer)-RH	1
11A 17796-B	Arm (outer)-LH	1
11A 17758	Bolt (arms to bar)	4
11A 17908	Bolt (guard to bar)	2
11A 17996-A	Guard (bumper)	2
†20472-S	Bolt (arm to frame)	6
350667-S2	Bolt (inner to outer arm)	4
33800-S8	Nut (inner to outer arm bolt)	4
33802-S8	Nut (arms to bar bolt)	4
33845-S8	Nut (arm to frame bolt)	6
44736-S8	Washer (inner arm to frame)	2
34808-S8	Lockwasher (inner to outer arm)	4
33845-S8	Nut (guard to bar bolt)	2
34849-S2	Lockwasher	12

1941

SEDAN DELIVERY



01A 17757-B	Bar	1
11C 17787-A	Arm (inner)-RH	1
11C 17788-A	Arm (inner)-LH	1
11C 17795-A	Arm (outer)-RH	1
11C 17796-A	Arm (outer)-LH	1
11A 17758	Bolt (arms to bar)	4
†20472-S	Bolt (arm to frame)	6
23381-S2	Bolt (inner to outer arm)	2
33802-S8	Nut (arms to bar bolt)	4
33845-S8	Nut (arm to frame bolt)	6
44736-S8	Washer (inner arm to frame)	2
34808-S8	Lockwasher (arms to bar bolt)	4
34849-S2	Lockwasher (arm to frame bolt)	4
34370-S8	Nut (inner to outer arm bolt)	2

† No Longer Supplied

1941

PASSENGER-SUPER DELUXE EXCEPT STATION WAGON



21A 17781-B	Bar	
11A 17787-A	Arm (inner)	
11A 17795-A	Arm (outer)	
11A 17908	Bolt (inner arm to bar)	
11A 17758	Bolt (outer arm to bar)	
11A 17996-B	Guard (bumper)	
†20472-S	Bolt (arms to frame)	
23381-S2	Bolt (inner to outer arm)	
33802-S8	Nut (outer arm to bar)	
33845-S8	Nut (arms to frame bolt)	
33846-S8	Nut (inner arm to bar bolt)	
34849-S2	Lockwasher	
34370-S8	Nut (inner to outer arm bolt)	

1941

PASSENGER EXCEPT SUPER DELUXE AND STATION WAGON



01A 17757-A	Bar	
11A 17787-C	Arm (inner)-offset design-RH	
11A 17788-C	Arm (inner)-offset design-LH	
11A 17795-C	Arm (outer)-offset design-RH	
11A 17796-C	Arm (outer)-offset design-LH	
11A 17758	Bolt (arms to bar)	
11A 17908	Bolt (guard to bar to inner arm)	
11A 17996-A	Guard (bumper)	
†20472-S	Bolt (arms to frame)	
23381-S2	Bolt (inner to outer arm)	
33802-S8	Nut (arms to bar bolt)	
33845-S8	Nut (arms to frame bolt)	
33846-S8	Nut (guard to bar to inner arm)	
34808-S8	Lockwasher (arms to bar bolt)	
34849-S2	Lockwasher	
34370-S8	Nut (inner to outer arm bolt)	